

M&R GASTRO SERVICE · REVISION 1.0

Technisches Servicedossier

Förderbandtoaster – 3,5 kW – 600 Scheiben/h

Nur für qualifiziertes Servicepersonal. Vor Arbeiten alle Energiequellen trennen, sichern und die Spannungsfreiheit prüfen.

Geltungsbereich: MRG.MEK010

01 Servicehinweise

- Explosionszeichnung und Ersatzteilliste sind im Handbuch enthalten.
- Elektrischer Schaltplan (Stromlaufplan) ist im Handbuch enthalten.

EXPLODED VIEW

Yes

WIRING

Yes

PARTS LIST

Yes

VISUAL PAGES

4

Installation, Anschluss, Wartung und Reparaturen dürfen nur durch qualifiziertes Fachpersonal erfolgen.

M&R Gastro Service

shop@mr-gastro.ch · +41 58 668 69 69

+41 58 668 69 69

M&R GASTRO SERVICE · REVISION 1.0

Dossier technique service

Toasteuse à convoyeur – 3,5 kW – 600 tranches/h

Réservé au personnel technique qualifié. Avant toute intervention, couper, condamner et vérifier l'absence de toute énergie.

Champ d'application: MRG.MEK010

01 Notes de service

- Dessin éclaté et liste des pièces de rechange fournis dans le manuel.
- Schéma électrique (circuit) inclus dans le manuel.

EXPLODED VIEW

Yes

WIRING

Yes

PARTS LIST

Yes

VISUAL PAGES

4

L'installation, le raccordement, l'entretien et les réparations doivent être réalisés par du personnel qualifié.

M&R Gastro Service

shop@mr-gastro.ch · +41 58 668 69 69

+41 58 668 69 69

M&R GASTRO SERVICE · REVISION 1.0

Dossier tecnico di assistenza

Tostatrice a nastro – 3,5 kW – 600 fette/h

Riservato al personale tecnico qualificato. Prima di ogni intervento scollegare, bloccare e verificare l'assenza di tutte le fonti di energia.

Campo di applicazione: MRG.MEK010

01 Note di assistenza

- Disegno esploso e elenco ricambi forniti nel manuale.
- Schema elettrico incluso nel manuale.

EXPLODED VIEW

Yes

WIRING

Yes

PARTS LIST

Yes

VISUAL PAGES

4

Installazione, collegamento, manutenzione e riparazioni devono essere eseguiti esclusivamente da personale qualificato.

M&R Gastro Service

shop@mr-gastro.ch · +41 58 668 69 69

+41 58 668 69 69

M&R GASTRO SERVICE · REVISION 1.0

Technical service dossier

Conveyor toaster – 3.5 kW – 600 slices/h

For qualified service personnel only. Before work, isolate, lock out and verify all energy sources are absent.

Scope: MRG.MEK010

01 Service notes

- Exploded view and spare-parts list are provided in the manual.
- Electric circuit schematic is included in the manual.

EXPLODED VIEW
Yes

WIRING
Yes

PARTS LIST
Yes

VISUAL PAGES
4

Installation, connection, maintenance and repairs must only be carried out by qualified personnel.

M&R Gastro Service

shop@mr-gastro.ch · +41 58 668 69 69

+41 58 668 69 69

MRG.MEK010

Verified technical reference

01 EXPLODED P2

CONVEYOR TOASTER

A GENERAL INFORMATION

Before installing the appliance, read operation and maintenance instructions carefully. Wrong installation and part changing may damage the product or may cause injury on people. These are not in our company's responsibility to damage the appliance intentionally, negligence, detriments because of disobeying instructions and regulations, wrong connections. Unauthorized intervention to appliance invalidates the warranty.

1. This instruction manual should be kept in a safe place for future reference.
2. Installation should be made in accordance with ordinances and security rules of that country by a qualified service personnel.
3. This appliance has to be used by trained person.
4. Please turn off the appliance immediately in the event of malfunction or failure. The appliance should be repaired only by authorized service personnel. Please demand original spare part.


MRG.MEK010

Verified technical reference

02 EXPLODED P9

CONVEYOR TOASTER

G SPARE PART LIST-EXPLODING DRAWING



MRG.MEK010

Verified technical reference

03 EXPLODED P10

CONVEYOR TOASTER

G SPARE PART LIST-EXPLODING DRAWING

PRODUCT CODE:		MEK010	
NO	PRODUCT NAME		P.CODE
1	ON-OFF SWITCH	Y	MEK010.001
2	SWITCH	Y	MEK010.002
3	ON-OFF BUTTON	Y	MEK010.003
4	SWITCH BUTTON	Y	MEK010.004
5	ON-OFF LAMP (RED)	Y	MEK010.005
6	SWITCH LAMP (GREEN)	Y	MEK010.006
7	MOTOR	Y	MEK010.007
8	RESISTANCE	Y	MEK010.008
9	CONVEYOR FRONT GEAR	Y	MEK010.009
10	CONVEYOR BACK GEAR	Y	MEK010.010
11	CONVEYOR WIRE	Y	MEK010.011
12	MOVEMENT NUT (SHAFT)	Y	MEK010.012
13	SIDE LID (RIGHT)	Y	MEK010.013
14	SIDE LID (LEFT)	Y	MEK010.014
15	CRUMB TRAY	Y	MEK010.015
16	BREAD TRAY	Y	MEK010.016
17	BREAD TRAY (BACK)	Y	MEK010.017
18	BREAD SLEDGE	Y	MEK010.018
19	SLEDGE FIXED	Y	MEK010.019
20	BREAD BIN FIXED	Y	MEK010.020
21	BREAD BIN	Y	MEK010.021
22	FEET	Y	MEK010.022
23	CONDENSATOR	Y	MEK010.023
24	SLEEVE	Y	MEK010.024
25	SUPPLY CABLE	Y	MEK010.025
26	SIDE RIGHT PANEL (OUTER)	Y	MEK010.026
27	FRONT PANEL (OUTER)	Y	MEK010.027
28	TOP LID	Y	MEK010.028
29	SIDE LEFT PANEL (OUTER)	Y	MEK010.029

MRG.MEK010

Verified technical reference

04 WIRING P11

CONVEYOR TOASTER

H ELECTRIC CIRCUIT SCHEMA

208V 1 PHASE

